

Auto Prompt Valve Operation



1) Water Off

Shower located vertically in dock water is off to hose and shower head



2) Water On

Remove shower head, turn shower dock 90° to horizontal to turn water on



3) Water Off

To replace shower in dock requires dock to be returned to vertical, turning off water.